









UWAGA: Podczas wysuwania rączki upewnij się, że obie strony są na tym samym poziomie.
UWAGA: Składanie i rozkładanie wózka możliwe jest wyłącznie przy wsuniętej rączce do pozycji 0.
UWAGA: Po złożeniu wózka sprawdź, czy mechanizm autoblokady siedziska działa prawidłowo. Jeśli to konieczne, dociśnij siedzisko do konstrukcji w pozycji złożonej.
UWAGA: Elementy ozdobne pokryte powłoką metalizowaną wymagają szczególnej ostrożności podczas użytkowania. Należy unikać kontaktu z ostrymi lub szorstkimi przedmiotami, które mogą spowodować zarysowania lub ścieranie powłoki. Uszkodzenia mechaniczne wynikające z niewłaściwego użytkowania nie podlegają reklamacji.

WARNING: When extending the handle, make sure both sides are at the same level.
WARNING: Folding and unfolding the stroller is only possible when the handle is fully retracted to position 0.
WARNING: After folding the stroller, check if the seat auto-lock mechanism is working properly. If necessary, press the seat firmly against the frame in the folded position.
WARNING: Decorative elements coated with a metallic finish require special care during use. Avoid contact with sharp or abrasive objects that may cause scratches or wear to the coating. Mechanical damage resulting from improper use is not covered by warranty.



BEBETTO



UWAGA: Zastosuj się do instrukcji i zaleceń na następnej stronie.
WARNING: Refer to the instructions and recommendations on the next page.



bebetto.eu



Monti

